



# Lenovo Vibe Z2 Pro Battery Replacement

In this short tutorial we will show how to replace the battery on the Lenovo Vibe Z2 Pro.

Written By: Bryan Sepulveda



## INTRODUCTION

If your phone is having issues holding a charge or the battery doesn't charge, it might be time to replace your phone's battery. Find out how to replace it in this guide


---



### TOOLS:


- [T4 Torx Screwdriver](#) (1)
  - [Spudger](#) (1)
-

## Step 1 — Lenovo Vibe Z2 Pro Backplate Disassembly




- Remove the 4.9 mm torx head screws located on the camera plate on the back of the phone

## Step 2



- Remove the 3.65 mm Torx head screws at the bottom of the phone.

## Step 3



- Remove the SIM card tray by pushing a pin into the hole on the side of the phone.

## Step 4



- Push the Spudger along the gap between the phone and the backplate to separate them.





## Step 5




- Carefully pull the backplate away from the phone.

## Step 6 — Battery




- Peel away protective the film using your hands.

# Step 7




- Remove any adhesive strips holding the battery in place gently using a fingernail or spudger.
- ⚠ The regular black nylon spudger should be used whenever possible, especially around batteries.

# Step 8



- Disconnect the orange battery ribbon cable by gently lifting with a spudger.

## Step 9



- Insert a fingernail or spudger into either side of the battery and lift upward.
- Remove the battery from phone.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 08:39:17 PM.